

CANMORE Golf GPS

User Guide



WARNING

Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty.

82-361G-01020

MAGNETIC ACCESSORY

The device equipped with a powerful magnet in the rear center of its housing. It allows the device to be securely attached to a golf cart bar, any metal surface or attached to the belt clip.



Magnet



Clip for attaching the unit to belt or golf bag



Extra magnet for attaching the unit to a golf cart bar tightly.




WARNING

Keep out of reach of children. If swallowed, get medical help or contact a Poison Control Center right away.

1.

[GPS Locating Tips] :

- Receive a GPS signal in an open space, and refer to the following instructions.
- GPS receiver is located in the middle of the device. Do NOT cover the receiver and face it towards the sky.
- The first positioning will take 2~5 minutes. Subsequent positioning will take 1~2 minutes.
- If you are unable to complete GPS positioning, press ① to exit. Move to an open space and try again.



1. Starting with the Device

At first time use, or after factory reset, or after software update, please choose language and set time. You can set the time by manual or by GPS. If you choose to set time by GPS, please refer to [GPS Locating Tips] on Page 1.

- Note:**
1. At first time use, please charge the device more than 2 hours in advance.
 2. If the battery runs out, time will need to be reset.

2. Device Overview

① Power/Backlight/Return

Hold to turn the device on/off.

Press to turn the backlight on/off.

Press to return to previous page or step.

② Up

Press to scroll up the menu.

③ OK/Enter

Press to accept an entry or to move forward on a menu.

④ Down

Press to scroll down the menu.



3.

3. Menu

1. Press **(3)** to enter main menu.
2. Press **(2)/(4)** to scroll up/down the menu.
3. Choose a selected function and press **(3)** to enter.



4. Settings

Press **(3)** to enter main menu. Use **(2)/(4)** to scroll to [SETTINGS]. Once in [SETTINGS], you will find following options :

- **Language** - Select your preferred language.
- **Clock** - Set time, alarm, toggle between 12-hour and 24-hour mode, summer time <1>, and sun rise/set time.
- **Backlight** - Set the duration for the backlight to remain on.
- **Alert** - Select either **Sound** or **Light** for your alert mode.
- **Unit** - Toggle between imperial/metric units.
- **GPS** - Search for GPS signal.
- **Factory Reset** - Reset the watch to factory settings.
- **About Watch** - Watch version number.

<1> *When summer time is on, the time will be adjusted one hour ahead.*

5. Golf Mode

This product is your digital golf caddy and contains thousands of golf course maps. It can locate where you are, detect your distance to the hole, show hazards and track your score.

5-1 Play Golf




1. Press ③ to enter main menu.
2. Select [PLAY GOLF], and press ③ to enter.
3. Satellites will be located automatically<2> and a list of golf courses will be shown by proximity.
4. Press ②/④ to scroll up/down, and press ③ to enter a selected golf course.

<2> Refer to [GPS Locating Tips] on Page 1.

5.

5-2 On The Course

When playing golf, you will notice that there are five metrics displayed on the screen. The list below explains what each of those pieces of information represents.



(a) #1 320

(b) Par4 258

227

(c) (d) (e)

(a) Current hole number.
(b) PAR for the hole.
(c) Distance to the back of green.
(d) Distance to the center of green.
(e) Distance to the front of green.

(The default unit is Yard. To switch the display unit, please refer to 4. Settings)

- Press (2)/(4) to go to next / previous hole.
- **Auto Hole:** The auto hole will trigger after the following conditions are met: Approach to within 30 yards of the center of the green, and then move at least 30 yards away from the center of the green.
- **Dual Green:** If the course has dual greens, hold (3) for three seconds to switch right / left green distance.

While in GOLF mode, follow below instruction to access Scorecard, Shot Distance, Hazard or Save this record.



Press (3) to enter Score Card, and use (2)/(4) to record your score of each hole. To save and exit, press (3).



Hold ② for 3 seconds to access Shot Distance. Travel to your ball, and the distance will be calculated. To return, press ①.



Hold ④ for 3 seconds to access the Hazard screen. To return, press ①.



To finish the round, press ①, and then press ③ to exit golf mode, or press ① to continue playing golf.

6. Score History


Score
2018.01.20
2018.01.18
2018.01.17
2018.01.15

Score	
1	- 9
10	- 18
Total	7
PAR	7
Score	7

Score		1-9	
H	P	S	
1	5	-1	
2	4	0	
3	3	1	
4	4	0	
5	3	1	

1. Press ③ to enter main menu.
2. Select [SCORE CARD], and press ③ to enter.
3. Press ②/④ to scroll up/down to check the history record.
4. To exit, press ①.
- 7.

7. Charge the Device



CHARGING PINS

CHARGING PORT

Battery / Charging Information

Battery Specifications: 3.7V / 400mAh

Charging Specifications: 5V / 500mA

Clean the charging contact port frequently to ensure the charging efficiency.

1. Attach the magnetic charger on the charging contacts located on the side of the device. Be sure the pins are aligned. Keep the device on a stable surface while charging.
2. Insert the USB end of the charging cord into a computer USB port or CE/FCC certified 5V output USB charger (exceeding 5V will void the warranty).

⚠ CAUTION

AVOID touching the magnetic end of the charging cable with metallic objects to prevent short circuits and damage to the cable. For safety reasons, after the device is fully charged, disconnect the charging cable from USB power source.

8. Troubleshooting



If any errors or malfunction occur, use factory reset at [SETTINGS → Factory Reset]. If that does not work, try hardware reset by pressing ③+④ together, and then press ①.

Release all three buttons at the same time.

9. Limited Warranty

The products are warranted to be free from defects in materials or workmanship for 12 Months from the date of purchase. Within the period, the manufacture will, as its sole option, repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor. The customer shall be responsible for any transportation cost.

The limited warranty does not apply to

1. Cosmetic damage, such as scratches, nicks and dents.
2. Consumable parts, such as batteries, watch band/ bungle, clip, iron, charging cable...etc. Unless product damage has occurred due to the defect in materials or workmanship.
3. Damage to a product that has been fallen accidentally, modified or altered without written permission of the manufacturer.
4. Damage to a product that has been connected to a non-CE/FCC certified 5V power supply.
5. Damage caused by failure to observe the safety instruction.

The manufacture reserves the right to refuse warranty claims against products or services that are obtained or used in contravention of the laws of any country. The device is intended

to be used only as a sport or leisure aid and must not be used for any purpose requiring precise measurement of direction, distance, and location. The manufacture makes no warranty to the accuracy or completeness of the course data.

To obtain warranty service, an original or copy of the sales receipt from the retailer is required. Securely pack the device and a copy of the original sales receipt. Send the device, freight charges prepaid.

10. Safety Instructions

Failure to heed the following warnings could result in an accident or medical event resulting in death or serious injury.

1. There is a built-in Li-polymer battery inside. Do not expose the device to fire, explosion, or other hazard.
2. Do not leave the device exposed to a heat source or in a high-temperature location, such as in the sun or in an unattended vehicle. To prevent the possibility of damage, remove the device from the vehicle or store it out of direct sunlight.
3. Do not operate the device outside of the temperature lower than 0 or over 45 degrees Celsius (from 32° to 113°F).
4. AVOID touching the magnetic end of the charging cable with metallic objects to prevent short circuits and damage to the cable. For safety reasons, after the device is fully charged, disconnect the charging cable from USB power source.

5. Do not disassemble, modify, remanufacture, drop, or puncture with forces.
6. Do not remove or attempt to remove the non-user replaceable battery.
7. Do not use while driving or be in any situations or environments require concentration.
8. The device trackers rely on sensors that track your movement and other metrics. The data provided by the device is intended to be a close estimation of your activity, but may not be completely accurate.
9. Contact your local waste disposal department to dispose the device in accordance with applicable local laws and regulations.

11. Contact Us

For further information, for golf course update, firmware renew, or any other support, please visit

<http://www.canmore-sport.com/>

*The content are subject to change without notice.
For latest user manual, please visit our website.*