

TW-411 Multi-Sport Watch

User Manual



WARNING


Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty.

[GPS Locating Tips] :

- Receive a GPS signal in an open space, and refer to the following instructions.
- GPS receiver is located at the bottom of the watch. Do NOT cover the receiver and face it towards the sky.
- The first positioning will take 2~5 minutes. Subsequent positioning will take 1~2 minutes.
- If you are unable to complete GPS positioning, press ② to exit. Move to an open space and try again.

Correct

✓ Open Space



Wrong



✗ Cover GPS Receiver



✗ Building Nearby



✗ In car



✗ Under eaves



✗ In house

1. Device Overview



① Power and Backlight

Hold to turn the device on/off.

Press to turn the backlight on/off.

② Back/Lap

Press to return to the previous page or step.

Switch time display mode.

③ Up

Press to scroll up the menus.

④ OK and Enter

Press to accept an entry or to move forward on a menu.

⑤ Down

Press to scroll down the menus.

2. Starting with the Watch

At first time use, or after factory reset, or after software update, please choose language and set time. You can set the time by manual or by GPS.

*If you choose to set time by GPS
please refer to [GPS Locating Tips] on Page 1.*

NOTE

1. At first time use, please charge the device more than 2 hours in advance.
2. If the watch battery runs out, time will need to be reset.

3. Time Mode



Under the Time Mode, press ② to switch Time display interface.

4. Watch Menu

1. Press ④ to enter main menu.
2. Press ③/⑤ to scroll up/down the menu.
3. Choose a selected function and press ④ to enter.



3.

5. Watch Settings

Press **(4)** to enter main menu. Use **(3)/(5)** to scroll to [SETTINGS]. Once in [SETTINGS], you will find the following options:

[Language] : Select your preferred language.

[Clock] : Set time, toggle between 12-hour and 24-hour mode, and Daylight Saving <1>.

[Backlight] : Set the duration for the back light to remain on.

[Alert] : Select either Sound, Light or Vibrate for your alert mode.

[Unit] : Toggle between imperial/metric units.

[Geolocation]: Set the format of GPS coordinate.

[SmartBand]: Turn on or off the Smartband.

[Orientation]: Choose to rotate the watch screen (180° or no rotate).

[Key lock] : Lock the watch buttons <2>.

[Factory Reset] : Reset the watch to factory settings.

[About Watch] : Check the Watch firmware and course version.

<1>When Daylight Saving is on, the time will be adjusted one hour head.

<2> To unlock Key Lock, press **(2)+(4)**, and release them together.

6. Fitness Calculators

Under the Time Mode, press ③/⑤ to browse the step walked, distance, and calories burned. Press ④ under each mode, you can set daily targets and set the achievement alarm.



- The Fitness calculator will be reset at 00:00am daily.
- To reset manually, please enter [Tools] → [Pedometer].

7. TOOLS

To set or view Alarm, Compass, Pedometer, Bubble Level, Timer or view your Geolocation.

8. Troubleshooting



If any errors or malfunctions occur, use factory reset. If that does not work try hardware reset.

Press ④+⑤ together, and then press ①. Release three buttons at same time.

9. Golf Mode


9-1 Play Golf



1. Press ④ to enter main menu.
2. Select [GOLF], and press ④ to enter.
3. Select [Play Golf], and press ④ to enter.
4. Satellites will be located automatically<3>, and a list of golf courses will be shown by proximity.
5. Press ③/⑤ to scroll up/down, and press ④ to enter a selected golf course.
<3> Refer to [GPS Location Tips] on Page 1.

9-2 On The Course

When playing golf, you will notice that there are five metrics displayed on the screen. The list below explains what each of those pieces of information represents.



(The default unit is Yard. To switch the display unit, please refer to 8. Watch settings)

- Press ③/⑤ to go to previous/next hole.
- Auto Hole: The auto hole will trigger after the following conditions are met: Approach to within 30 yards of the center of the green, and then move at least 30 yards away from the center of the green.
- Dual Green: If the course has dual greens, hold ④ for three seconds to switch right/left green distance.

While in GOLF mode. Follow below instructions to access Scorecard, Shot Distance, Hazard or Save this record.



Hold ⑤ for three seconds to access the Hazard screen, then press ③/⑤ to scroll up/down to see all Hazards. To exit, press ②.



Press ④ to enter score card, and then use ③/⑤ to enter your score. To save and exit, press ④.




Hold ③ for three seconds to access Shot Distance. Travel to your ball, and the distance will be calculated. To exit, press ②.




To finish the round, press ②. Press ③/⑤ to choose whether save the record, and then press ④ to confirm.

9-3 Golf Score History



1. Press (4) to enter main menu.
2. Press (4) to enter [Golf].
3. Press (4) to select [Score History].
4. Press (3)/(5) to select a history record, and press (4) to enter.
5. To return, press (2).

10. Charge the Watch



Battery/ Charging Information

Battery Specifications: 3.7V / 400mAh
Charging Specifications: 5V / 500mA

Clean the charging contact port frequently to ensure the charging efficiency.

1. Attach the magnetic charger on the charging contact located at the bottom of the watch. Be sure the pins are aligned. Keep the watch on a stable surface while charging.
2. Insert the USB end of the charging cord into a computer USB port or CE/FCC certified 5V output USB charger (exceeding 5V will void the warranty).

⚠ CAUTION

AVOID touching the magnetic end of the charging cable with metallic objects to prevent short circuits and damage to the cable.
For safety reasons, after the watch is fully charged, disconnect the charging cable from USB power source.

11. Limited Warranty

The products are warranted to be free from defects in materials or workmanship for 12 Months from the date of purchase. Within the period, the manufacture will, at its sole option, repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor. The customer shall be responsible for any transportation cost.

The limited warranty does not apply to

1. Cosmetic damage, such as scratches, nicks and dents.
2. Consumable parts, such as batteries, watch band/ bungle, clip, iron, charging cable...etc. unless product damage has occurred due to the defect in materials or workmanship.
3. Damage to a product that has been fallen accidentally, modified or altered without written permission of the manufacturer.
4. Damage to a product that has been connected to a non-CE/FCC certified 5V power supply.
5. Damage caused by failure to observe the safety instruction.

The manufacture reserves the right to refuse warranty claims against products or services that are obtained or used in contravention of the laws of any country. The device is intended to be used only as a sport or leisure aid and must not be used for any purpose requiring precise measurement of direction, distance, and location.

The manufacture makes no warranty to the accuracy or completeness of the course data.

To obtain warranty service, an original or copy of the sales receipt from the retailer is required. Securely pack the device and a copy of the original sales receipt. Send the device, freight charges prepaid.

12. Safety Instructions

Failure to heed the following warnings could result in an accident or medical event resulting in death or serious injury.

1. There is a built-in Li-polymer battery inside. Do not expose the device to fire, explosion, or other hazard.
2. Do not leave the device exposed to a heat source or in a high-temperature location, such as in the sun or in an unattended vehicle. To prevent the possibility of damage, remove the device from the vehicle or store it out of direct sunlight.
3. Do not operate the device outside of the temperature lower than 0 or over 45 degrees Celsius (from 32° to 113°F).
4. AVOID touching the magnetic end of the charging cable with metallic objects to prevent short circuits and damage to the cable. For safety reasons, after the watch is fully charged, disconnect the charging cable from USB power source.
5. Do not disassemble, modify, remanufacture, drop, or puncture with forces.

6. Do not remove or attempt to remove the non-user replaceable battery.
7. Do not use while driving or be in any situations or environments require concentration.
8. The device trackers rely on sensors that track your movement and other metrics. The data provided by the device is intended to be a close estimation of your activity, but may not be completely accurate.
9. Contact your local waste disposal department to dispose the device in accordance with applicable local laws and regulations.

13. Contact Us

For further information, for golf course update, firmware renew, or any other support, please visit

<http://www.canmore-sport.com/>

*The content are subject to change without notice.
For latest user manual, please visit our website.*